

AURA CHAIR

INSTRUCTIONS FOR ADJUSTMENT

workspace
commercial furniture

www.workspace.com.au
Sydney | Melbourne | Adelaide | Canberra | Brisbane



- ① **SEAT HEIGHT:** Pull up on the paddle lever and allow the gas-spring to lift the seat. Release the lever when the desired height is reached.
- ② **BACK TILT LOCK:** With the lever in the up position, push the backrest to the desired tilt position and then push the lever down to lock. To release simply pull the lever up.
- ③ **SEAT TILT SPRING TENSION:** Rotate the knob clockwise or anti-clockwise to increase or decrease tilt resistance.