

ADAPT CHAIR

INSTRUCTIONS FOR ADJUSTMENT

workspace
commercial furniture

www.workspace.com.au
Sydney | Melbourne | Adelaide | Canberra | Brisbane



- ① **SEAT HEIGHT:** Pull up on the paddle lever and allow the gas-spring to lift the seat. Release the lever when the desired height is reached.
- ② **SEAT FLIP:** Hold the chair steady, grip the front part of the seat and simply lift. This helps in stacking and storage.