

TRAX CHAIR INSTRUCTIONS FOR ADJUSTMENT

www.workspace.com.au Sydney | Melbourne | Adelaide | Canberra | Brisbane



- SEAT HEIGHT: Pull up on the paddle lever with fingertips and allow the gas-spring to lift the seat. Release the lever when the desired height is reached.
- ② SEAT DEPTH: Push the paddle lever down and slide the seat forward or backward. Release the lever when the seat is at the desired position.
- ③ SEAT TILT SPRING TENSION: Rotate the winder clockwise or anti-clockwise to decrease or increase tilt resistance.
- BACK TILT LOCK: Push the back-rest to the desired position and then push the left-handed paddle lever down to lock it in place. Pull the paddle lever up to release.
- (5) ARM HEIGHT ADJUSTMENT: Press the button on the front of either arm-rest to unlock. Then slide arm-rest up or down to the desired position and release button.
- 6 LUMBAR SUPPORT: Slide the lumbar support pad at the back of the chair up or down to required position.